

Issue 5 – 13.05.2022 B-Lab-For-009a

Page 1 of 2

## **BioLabTests**

Unit 3 Parade Court Central Boulevard, Prologis Park Coventry, CV6 4QL United Kingdom

Tel: +44 (0) 333 240 8308 Fax: +44 (0) 2476 338081 info@biolabtests.com www.biolabtests.com

## Certificate of Analysis

Customer Name: BIOCOTE on behalf of CONTOUR HEATING Date Received: 08.06.2023
Customer Contact: Rebecca Gill Date Analysed: 04.07.2023
Customer Email/Phone: rebecca.gill@biocote.com Date Reported: 06.07.2023

Certificate Number: BL025/2023

Tick box if customer has provided untreated control samples for inclusion in testing  $\qed$ 

## Test Method: Determination of Antibacterial Activity using Test Based on MOD ISO 22196: 2011

BioLabTests Sample					Contact Time*		Reduction against Initial	
Reference Number		Sample		Test Bacteria	0 Hrs	24 Hrs	Log <sub>10</sub>	%
230/214	BIOCOTE® PROTECTED PAINT		MRSA	5.17 x 10 <sup>4</sup>	4.67 x 10 <sup>2</sup>	2.04	99.10%	
230/214	BIOCOTE - PROTECTED PAINT			E. coli	5.07 x 10 <sup>4</sup>	1.03 x 10 <sup>3</sup>	1.69	97.96%

<sup>\*</sup>Numbers represent Colony Forming Units at representative contact times.

Data show the changes in size of the initial MRSA (ATCC® 43300 $^{\text{m}}$ ) and *E. coli* (ATCC® 8739 $^{\text{m}}$ ) populations due to their contact with the treated surface of the samples. The samples detailed in this CoA were tested for 24 hours ( $\pm 1$ ) at 35 $^{\circ}$ C ( $\pm 2$ ) under a relative humidity of >90% as specified in the ISO 22196 method. The results detailed in this CoA relate only to the items tested. This certificate shall not be reproduced except in full, without written approval of BioLabTests.

Please note; samples were received in a ready to test state from the customer apart from sterilisation which is noted below. All testing is performed on site at the BioLabTests address above unless otherwise disclosed.





Page 2 of 2

## **BioLabTests**

Unit 3 Parade Court Central Boulevard, Prologis Park Coventry, CV6 4QL United Kingdom

Tel: +44 (0) 333 240 8308 Fax: +44 (0) 2476 338081 info@biolabtests.com www.biolabtests.com

Noted during testing					
	Note				
No. of samples supplied per test:	6 of 6 supplied				
Sample size:	Average size: 50 x 50mm				
Sample sterilisation method:	65°C DRY HEAT FOR 1 HOUR				
Film size:	Average size: 40 x 40mm				
Inoculation volume:	Volume: 0.05ml				
Initial bacterial concentration:	MRSA: 1.03 x 10 <sup>6</sup> CFU/ml <i>E. coli</i> : 1.01 x 10 <sup>6</sup> CFU/ml				

The material of the cover slips is polyethylene with a thickness of 0.045mm.

Please note – For all information regarding deviations from ISO 22196:2011, please request statement B-Lab-State-007



Parmjit S Bilan BSc (Hons), CChem MRes Technical Manager, BioLabTests Ltd

**END OF REPORT** 

