

Issue 6 – 01.02.2024 B-Lab-For-009a

Page 1 of 2

BioLabTests

Unit 3 Parade Court Central Boulevard, Prologis Park Coventry, CV6 4QL United Kingdom

Tel: +44 (0) 333 240 8308 Fax: +44 (0) 2476 338081 info@biolabtests.com www.biolabtests.com

Certificate of Analysis

Customer Name:	BIOCOTE on behalf of CONTOUR HEATING	Date Received:	22.04.2024
Customer Contact:	Hayley Moore	Date Analysed:	14.05.2024
Customer Email/Phone:	hayley.moore@biocote.com	Date Reported:	16.05.2024
Certificate Number:	BL124/2024		

Tick box if customer has provided untreated control samples for inclusion in testing

Test Method: Determination of Antibacterial Activity using Test Based on MOD ISO 22196: 2011

BioLabTests Sample					Contact	: Time*		n against tial
Reference Number		Sample		Test Bacteria	0 Hrs	24 Hrs	Log ₁₀	%
240/131 BIO	вюсот	BIOCOTE® PROTECTED PAINT	MRSA	1.66×10^4	2.33 x 10 ²	1.85	98.59%	
	вюсо		E. coli	1.93 x 10 ⁴	≤100	≥2.29	≥99.48%	

*Numbers represent Colony Forming Units at representative contact times.

Data show the changes in size of the initial MRSA (ATCC[®] 43300^m) and *E. coli* (ATCC[®] 8739^m) populations due to their contact with the treated surface of the samples. The samples detailed in this CoA were tested for 24 hours (±1) at 35°C (±2) under a relative humidity of >90% as specified in the ISO 22196 method. The results detailed in this CoA relate only to the items tested. This certificate shall not be reproduced except in full, without written approval of BioLabTests.

Please note; samples were received in a ready to test state from the customer apart from sterilisation which is noted below. All testing is performed on site at the BioLabTests address above unless otherwise disclosed.





Page 2 of 2

BioLabTests

Unit 3 Parade Court Central Boulevard, Prologis Park Coventry, CV6 4QL United Kingdom

Tel: +44 (0) 333 240 8308 Fax: +44 (0) 2476 338081 info@biolabtests.com www.biolabtests.com

Noted during testing				
	Note			
No. of samples supplied per test:	6 of 6 supplied			
Sample size:	Average size: 35 x 35mm			
Sample sterilisation method:	65°C DRY HEAT FOR ONE HOUR			
Film size:	Average size: 25 x 25mm			
Inoculation volume:	Volume: 0.02ml			
Initial bacterial concentration:	MRSA: 8.29 x 10 ⁵ CFU/ml <i>E. coli</i> : 9.65 x 10 ⁵ CFU/ml			

The material of the cover slips is polyethylene with a thickness of 0.045mm.

Please note – For all information regarding deviations from ISO 22196:2011, please request statement B-Lab-State-007

Kmith

Richard Smith (BSc Hons) Laboratory Manager, BioLabTests Ltd



END OF REPORT